

demista[™]

bathroom cabinets



demista[™] Cabinets Fitting Instructions

1. Decide on position of cabinet and mark out the 4 screw holes.
2. Using fixings supplied, fit cabinet to wall.

NOTE: These fixings are only to be used when fitting to solid walls such as brick, concrete or blockwork

ALL ELECTRICAL CONNECTIONS MUST BE CARRIED OUT BY A QUALIFIED ELECTRICIAN IN ACCORDANCE WITH CURRENT REGULATIONS

Connect *demista*[™] cable to lighting or separate switch if required.

The circuit must be protected by a 5 amp fuse or circuit breaker at the distribution board.

The wires are coloured:

BLUE	-	NEUTRAL
BROWN	-	LIVE or POSITIVE

Wiring must be covered and inaccessible in compliance with relevant safety standards.

Any metal parts around the mirror must be earthed.